



## Perfect Exposure 1.0 – Quick step-by-step User Guide


- 1) Take a light frame with your camera (usually a 5 minutes exposure is enough but you may change it to your like)
- 2) With your favourite calibration software, open the frame and read the average background value
- 3) Open PerfectExposure
- 4) Insert the number of minutes of integration




- 5) Insert the background value found in 2)



- 6) Select your camera from the “Choose camera” list. If you don’t find it just insert manually your camera gain and readout noise (they are usually provided by the manufacturer).



- 7) Hit the “Calculate” button



- 8) Use the “Quit” button to exit the program